



# INVICTA

## Movement Caliber 8172 / 220

**INFO** Battery: 395-SR 57  
Service Life Battery: Without chrono = 57 months, with chrono 1H/D = 41 month 0312141 IM - B

## Movement Caliber : 8172 / 220

### Presentation

#### Display Elements

Second Hand

Minute Hand


Hour Hand

30 Minute Counter

Chronograph Hand

1/5 Second

Day



#### Control Buttons

**Push Button A**

Start / Stop

#### Crown Positions:

1. Normal position
2. Quick correction of date
3. Correction of hour, minute, day, date and second time zone / 24-hour


**Push Button B**

Split / Reset


## Movement Caliber : 8172 / 220

### Setting

#### Setting the Time



#### To Correct the Day




## Movement Caliber : 8172 / 220

### Setting

#### Setting the Date

Caution: Never correct date between 9pm and 0:30am.



## Movement Caliber : 8172 / 220

### Setting

After 2 hours of continuous running, the chrono stops and resets automatically to save the battery.



## Movement Caliber : 8172 / 220

Functions

### Measuring Split Times



## Movement Caliber : 8172 / 220

### Functions

#### After Battery Exchange or Mishandling Only

To reset chronograph, minute and second chronograph.

