


Function : Date, Second time zone / 24-hour

PRESENTATION

Display Elements
Minute Hand
Hour Hand
Second Hand
Second time zone / 24 hour
Date



Control Buttons

Crown Positions:

1. Normal position
2. Quick correct of date
3. Correction of hour, minute, date and second time zone/24-hour

Push Button B

- Quick correction of second time zone / 24-hour

INSTRUCTIONS MANUAL Cal.9232/1940

SETTINGS

Setting the Time

- 1 Pull the crown out to position 3.
- 2 Turn the crown clockwise to set the hour, minute and 24-hour hands to the desired time.
- 3 Push the crown back to position 1.



Setting the Second Time Zone

- 1 Set the crown at position 1.
- 2 Press B step-by-step to advance the hand of the second time zone by one hour per step until the desired time is set.
- 3 Stop pressing the button after finished the setting.



Setting the Date

- 1 Pull the crown to position 3.
- 2 Turn the crown clockwise. The date will advance 1 day when the time reaches 00:00 midnight. Continue to turn the crown until the desired date is set.
- 3 Push the crown back to position 1.



Quick Correction of Date

- 1 Set the crown out to position 2.
- 2 Turn the crown clockwise step-by-step to the desired date.
- 3 Push the crown back to position 1.

Please note:
Please do not set it between 21:00 and 00:30 midnight.



INFO

Battery: 371- SR920SW