



PRESENTATION



MANUAL

Cal.8N24

SETTINGS

Setting the Time

- 1.1 Pull the crown to position 2.
- 1.2 Turn the crown clockwise to set the hour / minute hand to the desired time.
- 1.3 Push the crown back to position 1.







INFO

Winding the Mainspring

- Automatic winding watch can also be hand winded by turning the crown clockwise in position ${f 1.}$
- Wind several times clockwise and it will start to move naturally.