


Function : Hour, Minute, Second & Date

PRESENTATION

Display Elements

Minute Hand
Hour Hand
Second Hand
Date



Control Buttons

Crown Positions:
1. Normal position
2. Quick correction of date
3. Setting of hour, minute, date

INSTRUCTIONS MANUAL Cal.K83/103

SETTINGS

Set the Time, Hour, Minute

- 1.1 Pull the crown to position 3.
- 1.2 Turn the crown clockwise to set hour/minute hands to the desired time.
- 1.3 Push the crown back to position 1.



1.1



1.2



1.3

Set the Date

- 2.1 Pull the crown to position 3.
- 2.2 Turn the crown clockwise. The date will advance 1 day when the time reaches 00:00 midnight. Continue to turn the crown until the desired date is set.
- 2.3 Push the crown back to position 1.



2.1



2.2



2.3

Quick Correction of Date

- 3.1 Set the crown to position 2.
 - 3.2 Turn the crown clockwise step-by-step to the desired date.
 - 3.3 Push the crown back to position 1.
- !! Attention !! Please Do Not set it between 21:00 and 00:30 midnight.



3.1



3.2



INFO

Battery: SR721 SW