


Function : Hour, Minute, Second & Date

PRESENTATION



INSTRUCTIONS MANUAL GP11

SETTINGS

Setting the Time

- 1.1 Pull the crown out to position 2.
- 1.2 Turn the crown to set hour and minute hands.
- 1.3 Push Crown back to normal position. Second Hand begins to run.



Setting the Date

- 2.1 Pull the Crown out to position 1.
- 2.2 Turn the crown clockwise to set the date.
*If the date is set between the hours of around 9:00PM and 2:00AM, the date may not change on the following day.
- 2.3 After the date has been set, push the crown back to the normal position.



INFO

Battery: SR920SW